

PARTS LIST

Key	Qty	Description
1	1	TOP LID
2	1	HANDLE, TOP LID
3	1	LOGO PLATE
4	2	RUBBER BUMPER, F/ TOP LID
5	1	TEMPERATURE GAUGE
6	1	BEZEL, F/ TEMP GAUGE
7	1	HARDWARE F/ TOP LID ASSEMBLY
8	1	WARMING RACK
9	1	CHEFS DELITE GRID/ TRAY
10	2	EMITTER, F/ COOKING GRATE, 120
11	2	COOKING GRATE, 120
12	1	EMITTER, F/ COOKING GRATE, 180
13	1	COOKING GRATE, 180
14	1	FIREBOX
15	2	LID STOP, FIREBOX
16	4	MAIN BURNER
17	1	ELECTRODE, F/ MAIN BURNER
18	1	ELECTRODE SET, F/ MAIN BURNER, 500MM WIRE
19	2	ELECTRODE SET, F/ MAIN BURNER, 600MM WIRE
20	4	BURNER BRACE
21	3	CARRYOVER TUBE
22	1	MAIN CONTROL PANEL
23	1	IGNITER SWITCH MODULE
24	1	VALVE ASSEMBLY
25	5	CONTROL KNOB
26	4	BEZEL F/ CONTROL KNOB
27	1	RIGHT SIDE SHELF
28	1	FASCIA, F/ RIGHT SIDE SHELF
29	1	SHELF SUPPORT, RIGHT
30	1	SEAR SIDEBURNER SHELF
31	1	FASCIA, F/ SB SHELF
32	1	SHELF SUPPORT, LEFT
33	1	LID, F/ SEAR SIDEBURNER
34	1	GRATE, F/ SEAR SIDEBURNER
35	1	FIREBOX, F/ SEAR SIDEBURNER

Key	Qty	Description
36	1	SEAR SIDEBURNER
37	1	ELECTRODE, F/ SEAR SIDEBURNER
38	1	SIDEBURNER VALVE BRACKET
39	3	WIRE CLIP
40	1	GREASE TRAY, F/ SEAR SIDEBURNER
41	1	BEZEL, F/ SIDEBURNER
42	1	CART SIDE PANEL, LEFT
43	1	CART SIDE PANEL, RIGHT
44	1	FRONT DOOR BRACE
45	2	MAGNET ASSEMBLY
46	2	DOOR PIN, SPRING
47	1	LEFT DOOR, NO HANDLE
48	2	HANDLE, F/ DOOR
49	1	RIGHT DOOR, NO HANDLE
50	1	BOTTOM SHELF
51	2	TANK SUPPORT
52	2	DOOR PIN, FIXED
53	1	REAR CART PANEL
54	1	HEAT SHIELD, F/ TANK
55	2	CASTER, LOCKING
56	2	CASTER, FIXED
57	1	MATCH HOLDER
58	1	GREASE TRAY
59	2	GREASE TRAY BRACKET
60	1	GREASE PAN
61	1	ELECTRONIC IGNITION MODULE
62	1	CAP, F/ ELECTRONIC IGNITION MODULE
63	2	TOOL HOLDER
64	1	TANK STRAP

NOT PICTURED

...	1	PRODUCT GUIDE, EUROPE
...	1	HARDWARE PACK
...	1	CASTER PIN
...	1	EMITTER CLEANING TOOL
...	1	REGULATOR HOSE CLIP (IF REQUIRED)

PARTS DIAGRAM

