

PARTS LIST

Key	Qty	Description
1	1	TOP LID
2	1	HANDLE, TOP LID
3	1	LOGO PLATE
4	2	RUBBER BUMPER, F/ TOP LID
5	1	TEMPERATURE GAUGE
6	1	BEZEL, F/ TEMP GAUGE
7	1	HARDWARE F/ TOP LID ASSEMBLY
8	1	WARMING RACK
9	1	EMITTER, F/ COOKING GRATE, 120
10	1	EMITTER, F/ COOKING GRATE, 180
11	1	COOKING GRATE, 120
12	1	COOKING GRATE, 180
13	1	FIREBOX
14	2	LID STOP, FIREBOX
15	2	MAIN BURNER
16	1	ELECTRODE, F/ MAIN BURNER
17	1	ELECTRODE SET, F/ MAIN BURNER, 500MM WIRE
18	2	BURNER BRACE
19	1	CARRYOVER TUBE
20	1	MAIN CONTROL PANEL
21	1	IGNITER SWITCH MODULE
22	1	VALVE ASSEMBLY
23	3	CONTROL KNOB
24	2	BEZEL F/ CONTROL KNOB
25	1	RIGHT SIDE SHELF
26	1	FASCIA, F/ RIGHT SIDE SHELF
27	1	SHELF SUPPORT, RIGHT
28	1	SEAR SIDEBURNER SHELF
29	1	FASCIA, F/ SB SHELF
30	1	SHELF SUPPORT, LEFT
31	1	LID, F/ SEAR SIDEBURNER
32	1	GRATE, F/ SEAR SIDEBURNER
33	1	FIREBOX, F/ SEAR SIDEBURNER
34	1	SEAR SIDEBURNER
35	1	ELECTRODE, F/ SEAR SIDEBURNER

Key	Qty	Description
36	1	SIDEBURNER VALVE BRACKET
37	3	WIRE CLIP
38	1	GREASE TRAY, F/ SEAR SIDEBURNER
39	1	BEZEL, F/ SIDEBURNER
40	1	CART SIDE PANEL, LEFT
41	1	CART SIDE PANEL, RIGHT
42	1	FRONT DOOR BRACE
43	2	MAGNET ASSEMBLY
44	1	DOOR PIN, SPRING
45	1	DOOR, NO HANDLE
46	1	HANDLE, F/ DOOR
47	1	BOTTOM SHELF
48	2	TANK SUPPORT
49	1	DOOR PIN, FIXED
50	1	REAR CART PANEL
51	1	HEAT SHIELD, F/ TANK
52	2	CASTER, LOCKING
53	2	CASTER, FIXED
54	1	MATCH HOLDER
55	1	GREASE TRAY
56	2	GREASE TRAY BRACKET
57	1	GREASE PAN
58	1	ELECTRONIC IGNITION MODULE
59	1	CAP, F/ ELECTRONIC IGNITION MODULE
60	2	TOOL HOLDER
61	1	TANK STRAP

NOT Pictured

...	1	PRODUCT GUIDE, EUROPE
...	1	HARDWARE PACK
...	1	CASTER PIN
...	1	EMITTER CLEANING TOOL
...	1	REGULATOR HOSE CLIP (IF REQUIRED)

NOTE: Some grill parts shown in the assembly steps may differ slightly in appearance from those on your particular grill model. However, the method of assembly remains the same.

DIAGRAM

